


# Design of Structural Steelwork

W. M. C. MCKENZIE

1925



© W.M.C. McKenzie 1998

All rights reserved. No reproduction, copy or transmission of this publication may be made without written permission.

No paragraph of this publication may be reproduced, copied or transmitted save with written permission or in accordance with the provisions of the Copyright, Designs and Patents Act 1988, or under the terms of any licence permitting limited copying issued by the Copyright Licensing Agency, 90 Tottenham Court Road, London W1P 9HE.

Any person who does any unauthorised act in relation to this publication may be liable to criminal prosecution and civil claims for damages.

The author has asserted his right to be identified as the author of this work in accordance with the Copyright, Designs and Patents Act 1988.

First published 1998 by  
MACMILLAN PRESS LTD  
Houndsborough, Basingstoke, Hampshire RG21 6XS  
and London  
Companies and representatives throughout the world

ISBN 0-333-71579-9

A catalogue record for this book is available from the British Library.

This book is printed on paper suitable for recycling and made from fully managed and sustained forest sources.

10 9 8 7 6 5 4 3 2 1  
07 06 05 04 03 02 01 00 99 98

Printed in Malaysia

# Contents

Preface	xii
Acknowledgements	xiii
<b>1. Structural Steelwork</b>	1
1.1 Introduction	1
1.2 The Design Process	5
1.2.1 <i>Aims of Design</i>	5
1.2.2 <i>Structural Loading</i>	6
1.2.3 <i>Structural Analysis and Load Distribution</i>	8
1.3 Example 1.1 Load distribution one-way spanning slabs	8
1.4 Example 1.2 Two-way spanning slabs	9
1.5 Example 1.3 Secondary beams	11
1.6 Example 1.4 Combined one-way, two-way slabs and beams	12
1.7 Limit State Design BS 5950:Part 1: 1990	13
1.7.1 <i>Ultimate Limit State</i>	14
1.7.2 <i>Serviceability Limit State</i>	14
1.7.3 <i>Partial Safety Factors</i>	14
1.7.4 <i>Application of Partial Safety Factors</i>	14
1.8 Example 1.5 Brewery part floor plan load distribution	15
1.9 Application of Wind Loads	18
1.10 Example 1.6 Storage hopper	18
1.11 Example 1.7 Industrial warehouse	22
1.12 Example 1.8 Radar reflector	32
<b>2. Flexural Members</b>	34
2.1 Introduction	34
2.1.1 <i>Plastic Sections</i>	37
2.1.2 <i>Compact Sections</i>	38
2.1.3 <i>Semi-Compact Sections</i>	38
2.1.4 <i>Slender Sections</i>	38
2.2 Shear Capacity ( <i>Clause 4.2.3</i> )	39
2.3 Example 2.1 Shear check of a simply supported beam	40
2.4 Moment Capacity ( <i>Clause 4.2.5</i> )	41
2.4.1 <i>Compression Flange Restraint</i>	41
2.4.2 <i>Effective Length <math>L_e</math></i> ( <i>Clauses 4.3.5 and 4.3.6</i> )	44
2.4.3 <i>Moment Capacity (<math>M_c</math>) of Beams with Full Lateral Restraint</i>	46
2.5 Example 2.2 Bending in fully restrained beam	47
2.6 Moment Capacity ( $M_b$ ) of Beams without Full Lateral Restraint ( <i>Clause 4.3.7</i> )	48
2.6.1 <i>Rigorous Method</i> ( <i>Clause 4.3.7.1</i> )	48
2.7 Example 2.3 Beam with intermittent lateral restraint	49

2.8 Example 2.4 Beam with intermittent lateral restraint	53
2.9 Example 2.5 Rectangular hollow section as a beam	56
2.10 Example 2.6 Cantilever beam	57
2.11 Web Buckling and Web Bearing	60
2.11.1 <i>Web Buckling (Clause 4.5.2)</i>	61
2.11.2 <i>Web Bearing (Clause 4.5.3)</i>	62
2.12 Example 2.7 Web bearing and web buckling at support	63
2.13 Deflection of Beams ( <i>Clause 2.5.1</i> )	65
2.13.1 <i>Equivalent UDL Technique</i>	66
2.14 Example 2.8 Deflection of simply supported beam	68
2.15 Conservative Method for Lateral Torsional Buckling Moment Capacity ( <i>Clause 4.3.7.7</i> )	70
2.16 Example 2.9 Simply supported beam 1 – conservative method	70
2.17 Example 2.10 Simply beam 2 – conservative method	71
2.18 Safe Load Tables	72
2.19 Example 2.11 Beam with intermittent lateral restraint - Use of safe load tables	73
2.19.1 <i>Shear</i>	75
2.19.2 <i>Bending</i>	75
2.19.3 <i>Web Buckling</i>	75
2.19.4 <i>Web Bearing</i>	76
2.19.5 <i>Deflection</i>	76
2.20 Example 2.12 Pedestrian walkway	77
2.21 Solution to Example 2.2	78
2.22 Solution to Example 2.12	82
<b>3. Axially Loaded Members</b>	<b>86</b>
3.1 Introduction	86
3.2 Pin-jointed Frames	87
3.3 Résumé of Analysis Techniques	90
3.3.1 <i>Method of Sections</i>	90
3.4 Example 3.1 Pin-jointed truss	91
3.4.1 <i>Joint Resolution</i>	93
3.4.2 <i>Tension Coefficients</i>	96
3.5 Example 3.2 Two dimensional plane-truss	97
3.6 Example 3.3 Three dimensional space truss	98
3.7 Design of Tension Members ( <i>Clause 4.6</i> )	99
3.8 Example 3.4 Lattice girder	105
3.9 Design of Compression Members ( <i>Clause 4.7</i> )	106
3.9.1 <i>Slenderness (Clause 4.7.3)</i>	107
3.9.2 <i>Compressive Resistance (Clause 4.7.4)</i>	109
3.10 Example 3.6 Secondary bracing in lattice girder	114
3.11 Example 3.7 Concentrically loaded single storey column	118
3.12 Column Baseplates	120
3.13 Example 3.7 Slab base	121

<b>Members Subject to Combined Axial and Flexural Loads</b>	123
<b>4.1 Introduction</b>	123
<i>4.1.1 Combined Tension and Bending</i>	123
<i>4.1.2 Reduced Moment Capacity</i>	125
<i>4.1.3 Combined Compression and Bending</i>	127
<b>4.2 Eccentricity of Loading</b>	129
<b>4.3 Section Classification</b>	130
<b>4.4 Example 4.1 Industrial unit</b>	130
<b>4.5 Columns in Simple Multi-Storey Construction (Clause 4.7.7)</b>	135
<b>4.6 Example 4.2 Multi-storey column in simple construction</b>	136
<b>4.7 Example 4.3 Lattice girder with secondary bending</b>	141
 <b>Connections</b>	145
<b>5.1 Introduction</b>	145
<i>5.1.1 Simple Connections</i>	146
<i>5.1.2 Moment Connections</i>	147
<b>5.2 Bolted Connections</b>	153
<i>5.2.1 Black Bolts</i>	153
<i>5.2.2 High Strength Friction Grip Bolts (H.S.F.G.)</i>	156
<i>5.2.3 Design of Simple Connections</i>	158
<b>5.3 Welded Connections</b>	159
<i>5.3.1 Fillet Welds</i>	160
<i>5.3.2 Butt Welds</i>	161
<i>5.3.3 Design of Fillet Weld Connections</i>	162
<b>5.4 Beam End Connections</b>	164
<i>5.4.1 Double-Angle Web Cleats</i>	164
<i>5.4.2 Flexible End Plates</i>	165
<i>5.4.3 Fin Plates</i>	165
<b>5.5 Example 5.5 Web cleat, end plate and fin plate connections</b>	166
<b>5.6 Design of Moment Connections</b>	167
<i>5.6.1 Typical Site Connection Using H.S.F.G. Bolts</i>	168
<i>5.6.2 Example 5.6 Moment connection in rectangular portal frame</i>	168
<i>5.6.3 Example 5.7 Crane bracket moment connection</i>	170
<b>5.7 Splices</b>	171
<i>5.7.1 Beam Splices</i>	171
<i>5.7.2 Example 5.8 Beam splice</i>	172
<i>5.7.3 Column Splices</i>	178
<i>5.7.4 Example 5.9 Column splice</i>	180
<b>5.8 Solution to Example 5.1</b>	183
<b>5.9 Solution to Example 5.2</b>	185
<b>5.10 Solution to Example 5.5</b>	187
<b>5.11 Solution to Example 5.6</b>	196

<b>6. Plate Girders</b>	198
6.1 Introduction	198
<i>6.1.1 Design Load Effects</i>	200
6.2 Initial Sizing	201
6.3 Moment and Shear Capacity	201
6.4 Deflection	203
6.5 Intermediate Stiffeners	203
6.6 Load Bearing Stiffeners	203
6.7 Example 6.1 Plate girder in multi-storey office block	203
<i>6.7.1 Design Loading</i>	205
<i>6.7.2 Column Loads</i>	205
<i>6.7.3 Initial Sizing</i>	206
<i>6.7.4 Section Classification (Clause 3.5)</i>	207
<i>6.7.5 Flanges</i>	207
<i>6.7.6 Web</i>	208
<i>6.7.7 Moment Capacity (Clause 4.4.4.2(a))</i>	209
<i>6.7.8 Shear Capacity (Clause 4.4.5.3)</i>	209
<i>6.7.9 Deflection (Clause 2.5)</i>	210
<i>6.7.10 Intermediate Stiffeners (Clause 4.4.6)</i>	212
<i>6.7.11 Load Bearing Stiffeners (Clause 4.5)</i>	213
<i>6.7.12 Flange to Web Connection</i>	217
6.8 Example 6.2 Plate girder with intermittent restraint to flange	218
6.9 Solution to Example 6.2	219
<b>7. Concise Eurocode 3 C-EC3</b>	230
7.1 Introduction	230
<i>7.1.1 National Application Document (NAD)</i>	230
<i>7.1.2 Concise EC3 (C-EC 3)</i>	230
7.2 Terminology, Symbols and Conventions	231
<i>7.2.1 Decimal Point</i>	231
<i>7.2.2 Actions</i>	231
<i>7.2.3 Resistance</i>	232
<i>7.2.4 Subscripts</i>	232
<i>7.2.5 Design Values</i>	232
<i>7.2.6 Partial Safety Factors</i>	232
<i>7.2.7 Symbols</i>	233
<i>7.2.8 Conventions</i>	234
<i>7.2.9 Materials</i>	235
7.3 Section Classification	236
7.4 Use of C-EC 3	236
<i>7.4.1 Example 7.1 Beam with full lateral restraint</i>	236
7.5 Lateral Torsional Buckling (LTB) (Clause 5.5.5)	246
7.6 Example 7.2 Beam with intermediate and end restraints	247
7.7 Example 7.3 Truss members with axial tension/compression	251
7.8 Example 7.4 Concentrically loaded single storey column	256

7.9 Axially Loaded Members with Moments	260
7.10 Example 7.5 Multi-storey column in simple construction	263
<b>Bibliography</b>	<b>270</b>
<b>Index</b>	<b>272</b>